



#### 12 MONTHS GUARANTEE

WE OFFERS PRODUCTS OF THE HIGHEST QUANTITY SHOULD ANY DEFECT APPEAR WITHIN 12 MONTHS OF DATE OF PURCHASE£¬ PLEASE RETURN THE PRODUCT WITH PROOF OF PURCHASE TO US, AND WE WILL REPAIR OR REPLACE IT FREE OF CHARGE.. THIS GUARANNTEE DOES NOT AFFECT YOUR STATUTORY RIGHTS.


# **ATTENTION**

- 1. Read this operation manual carefully before using.
- 2. Keep the machine separately from children.
- 3. Keep the machine away from fire and liquid.
- 4. Put the machine on a stable and safe place in order to prevent if from falling or causing any injury to people or the machine itself.
- 5. Test the machine with some scrap paper before formally punching and binding, to make sure whether the position is correct to punch.

# COIL(SPIRAL) BINDING MACHINE MANUAL



#### **SPARE PARTS LIST**



### **SPECIFICATIONS**

### **Manual Coil(Spiral) Binding Machine**

Maximum Binding Capacity: Arbitrary;;  Max. Binding Width: Below 300mm;	
Adjustable Margin: 2.5, 4.5, 6.5mm;	
Number of holes: 46 holes;	
Quantity of Movable Cutter : all	
Hole Distance: 6. 35mm	
Size of Machine:435x335x205mm;	
Net Weight: 9.5kgs;	

### **OPERATION GUIDE**

PLACE THE MACHINE ON A STABLE AND SAFE PLACE BEFORE USING.

## **Punching and binding operation**













# Clean up the waste paper box

- 1. Pull out the waste paper box from the bottom of the machine, clean it and insert it back again.
- 2. Please clean up the waste paper box frequently.