



S300BOM

55	Up guide plate	S310-02-014
54	Margin set	S300-04-05
53	Plastic bearing 2	S60-13-01
52	Spring screw	S100-28-01/02
51	Reset spring	DE-16-001-01
50	Plastic Bearing 1	S100-01-01
49	Square shaft	S300-02-10
48	Gear	S60-29
47	Top cover	S300-05-02
46	Back cover	S300-05-04
45	Slider	S300-03-04
44	Bindign adjusting pole	S300-03-05
43	Binding spring support	S310-03-021
42	Binding pointer	S310-03-003
41	Paper stop/Binding Knob	S300-03-019
40	Binding cover	S300-05-03
39	Binding plate 1	S300-03-01
38	Binding plate 2	S300-03-02
37	Punch pin	S300-02-04A/E
36	Engagement pin support 3	S310-02-007
35	Washer	S300-02-008
34	Press plate	S300-02-05
33	Limit plate	S300-02-09
32	Rack	S300-02-06/07
31	Engagement pin support 2	S310-02-009
30	Washer 3	S310-02-006-02
29	Washer 2	S300-02-02-A
28	Bottom guide plate	S300-02-001
27	Washer 1	S300-02-02-B
26	Punch plate	S300-02-002
25	Small left frame	S300-01-05
24	Left frame	S300-01-02
23	Paper stop screw	S100-36-01
22	Paper stop	S100-37-01
21	Binding spring	S310-01-05-09
20	Base	S60-04-01
19	Drawer guider	S300-01-01
18	Waste paper drawer	S60-17-01
17	Rubber protector	S100-35-01
16	Margin bar	S300-04-09
15	Margin spring	S310-03-020
14	Shifting fork	S310-03-012
13	Left/mid margin shaft support	S300-04-11
12	Margin bar connector	S300-04-03
11	Right margin shaft support	S300-04-08
10	Margin shaft	S300-04-02
9	Reset spring chip	S300-04-10
8	Margin knob	S300-04-01
7	Paper support	S300-05-05
6	Wire hook	S300-05-06
5	Front cover	S300-05-01
4	Small right frame	S300-01-04
3	Right frame	S300-01-03
2	Handle	S60-10-01
1	Handle screw	S60-26-01
Item	Desc.	Material No.