



S310BOM

60	Up guide plate	S310-02-015
59	Margin bar	S310-03-011
58	Margin shaft	S310-03-016
57	Shifting fork	S310-03-012
56	Right binding frame	S310-01-007-02
55	Reset spring	DE-16-001
54	Round beam	S310-01-006
53	Binding plate 2	D310-01-017
52	Binding shaft	S310-01-015
51	Binding gear	S310-01-014
50	Binding plate 1	S310-03-001
49	Binding spring support	S310-03-021
48	Silder	S310-03-004
47	Back cover	S310-04-006-01
46	Binding adjusting pole	S310-03-006
45	Wire fixing plate	S310-04-004
44	Binding pointer	S310-03-003
43	Binding cover	S310-04-005
42	Top cover	S310-04-003
41	Plate fixing spring	S310-03-009-01
40	Small shaft	S310-03-022
39	Spring screw	S100-28-01/02
38	Binding rail	S310-03-005
37	Rack	S310-02-014
36	Rack base	S310-02-013-01/02
35	Punch pin	S310-02-005
34	Engagement pin support 3	S310-02-007
33	Press plate	S310-02-015-1
32	Washer	S300-02-008
31	Engagement pin support 2	S310-02-009
30	Spring chip	S310-02-010
29	Engagement pin support 1	S310-02-011
28	Engagement pin	S310-02-012
27	Washer 3	S310-02-006-02
26	Washer 2	S310-02-006-03
25	Bottom guide plate	S310-02-002
24	Washer 3	S310-02-006-01
23	Punch plate	S310-02-013
22	Binding spring	S310-01-05-09
21	Left binding frame	S310-01-007-01
20	Bottom plate	S310-01-005
19	Binding handle	S310-01-016
18	Left frame	S310-01-001
17	Margin spring	S310-03-020
16	Rubber protector	S100-35-01
15	Square beam	S310-01-004
14	Fix plate	S310-01-021
13	Paper stop/Binding knob	S310-03-019
12	Paper stop	S310-03-017
11	Paper stop set	S310-03-018
10	Waste paper drawer	S310-01-003
9	Down-front cover	S310-04-001
8	Up-front cover	S310-04-002
7	Punch gear	S310-01-014
6	Punch shaft	S310-02-012-01
5	Margin set	S310-03-012
4	Right frame	S310-01-002
3	Margin knob	S310-03-014
2	Punch handle	S310-01-011
1	Handle screw	S60-26-01
Item	Desc.	Material No.